User Manual

Skiva AudioFlow BigSound S-1
15W Stereo Portable Bluetooth Speaker
with 3000mAh Rechargeable Battery

Document Revision No.: 1.0

SP101

Overview:

Skiva AudioFlow BigSound is powerful (15W), compact and portable Bluetooth speaker designed for the music lovers to enhance their music experience. BigSound comes with 3000mAh rechargeable Lithium battery inside, which provides around 8 hours of playtime. It supports easy pairing with Bluetooth enabled devices, and you can also use it via 3.5mm Aux-in cable. The built-in microphone can be used for hands-free speaker phone calling. AudioFlow BigSound not only makes your music world simple, but also fabulous.

Explore AudioFlow BigSound:



(c) 2014 Skiva Technologies, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.

Features:

- BigSound with its 15 W speaker gives out loud neat and clean sound which enhances your music experience.
- 3000mAh rechargeable battery provides play time of up to 8 hours and also full freedom from wire cluttering or plugin to play.
- Equipped with Bluetooth CSR V4.0 making Bluetooth pairing child's play. Also enabled to adjust Volume and other control functions such as play, pause, skip and speakerphone from a distance of up to 10 meters.
- Compact and palm sized design makes BigSound all time portable. Hence, your ideal companion for outdoor use such as for camping, picnic etc. Letting you enjoy your music to the fullest.
- In-built Microphone allows for incoming calls to be answered without touching the paired device.
- Compatible with almost all Bluetooth enabled devices. Handy, Light weight and user friendly.

Getting Started :

1. Switching ON/OFF the Speaker

Slide the power button on the backside of BigSound to Bluetooth/Aux mode. It will turn ON the speaker and then BigSound can be used in respective Bluetooth or Aux mode. This mode selection is notified by sound.

- *Bluetooth mode* - for playing music via Bluetooth from mobile/tablets/smartphones.
- *Aux mode* - for playing music via provided line-in cable.

To Switch OFF BigSound, slide the same button again to the original position ⏻ .

(c) 2014 Skiva Technologies, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.

Note:
When Bluetooth pairing is not successful; BigSound Speaker will enter into standby mode automatically. Speaker will power off automatically if not connected successful within 5 minutes.

2. Charging

When the speaker's battery is low the LED indicator flashes RED, a reminder to charge your device

- Plug the micro USB cable into the input port of the speaker.
- Insert the other end of the cable to a power source (Laptop/USB adapter – not included).

Battery Indicator

- Low battery: The LED indicator alternately flashes fast in red.
- Battery charging: The LED indicator glows Red constantly.
- Fully charged: The LED indicator turns OFF.

3. Bluetooth Pairing

- Select Bluetooth mode from power button to switch BigSound into pairing mode.
- On the front side of speaker check whether a red and blue LED light flashes alternatively or not. If no then press pairing button for 5 sec to switch Speaker into pairing mode.
- Activate your device's Bluetooth function and search for the available Bluetooth devices.
- Once the Bluetooth speaker has been detected select Skiva Speaker 1 from the list and pair with it. Pairing message will also be displayed on your mobile device. Use "0000" as password if asked by the device, and press OK to complete the pairing process.

Note:

- If BigSound is already paired with a device, then connection is automatically established within 30 seconds. If pairing takes more than 2 minutes to connect then please repeat the above steps.

(c) 2014 Skiva Technologies, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.

- You need to choose select ‘use it as audio equipment (stereo)’ or similar link from the Bluetooth menu if a Computer/PC is being paired with Bluetooth speaker.
- If BigSound is already paired with an active device and still you want to pair with new device then you need to unpair previous device and pair new device again.

4. NFC Pairing

- Select NFC Function to ‘Open Status’ on your Smartphone or other devices supporting NFC.
- Switch BigSound Speaker to Bluetooth mode.
- Bring your Smartphone/NFC device close to BigSound Speaker NFC induction area (on right side of BigSound).
- A message will appear on Smartphone screen. Select ‘Yes’ and enjoy your favorite music on BigSound.

Note:
The NFC antenna may not work in the same position for every Smartphone/NFC device. So, please try alternating the position and angle of your Smartphone to a position that gets you Smartphone paired with BigSound.

5. Aux Pairing

- Switch to Aux status from power button panel.
- Insert the Aux-in cable to Speaker.
- Insert the provided 3.5mm audio plug to your music source like Phone or Laptop. Once connected, BigSound will automatically start playing the music selected on Phone or Laptop.

6. Some common controls:

- **Music Controls:**

  "V +": Hold & press (Long press) for volume up, short press for playing next song.

  "V -": Hold & press (Long press) for volume down, short press for playing previous song.

  Short press for music play and pause.

(c) 2014 Skiva Technologies, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.

Note:
You can also control above operation by choosing the correct option from your smart devices.

- **Answering/Declining an Incoming call:**

  Receiving/Declining an incoming call on your phone when it is connected with BigSound is now easier than ever. Just press (short press) the pairing button to receive and quickly press the same button twice to reject incoming call respectively. A built-in micro phone provides for hands free operation.

- **Reset Function Operation:**
  - Put the BigSound to Standby mode.
  - Long press and Hold the "V +" and "V -" button at the same time for 5 seconds. This will be notified by a small beep sound and BigSound will reset.
  - Now the speaker can again be paired by following the steps mentioned under Bluetooth Pairing in Getting Started

  Warning:
  If you reset your Speaker then all the previous paired records will be removed automatically.

Usage Tips:

- It is advised that you charge the speaker before using it for the first time.
- While pairing any device with BigSound Speaker, it is recommended to maintain a distance of 1 meter.
- The operational range of the speakers may be influenced by obstructions like walls, pillars. If there are any obstacles between BigSound and connected device, then the control distance will be shortened. Hence avoiding such obstructions whenever possible would results in crystal clear sound.
- Do not expose the speaker or any of its components to rain or other liquids.

(c) 2014 Skiva Technologies, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.

- Avoid using BigSound during the charge process, to maintain long-term performance.
- Do not use solvents like alcohol, benzene for cleaning.
- Under normal use BigSound may emit slight heat, ensuring proper ventilation to the unit reduces such occurrences.
- If the speaker is left un-used for long periods, make sure the power is off and alternatively charge it at least once in 3 months.
- In any case do not attempt/try to repair BigSound by yourself; doing so will result in getting the warranty voided.

For support please contact us at (888) 754-8211
or via e-mail at support@skivatech.com.

(c) 2014 Skiva Technologies, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.

(c) 2014 Skiva Technologies, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.